






- DO NOT ALTER THIS DRAWING.
- THIS IS A REFERENCE DRAWING ONLY.
- SEE SolidWorks FILE FOR DETAILS
- IF IN DOUBT ASK.

- REMOVE ALL BURRS AND SHARP EDGES.
- CLEAN AND FULLY DEGREASE.
- ALL WELDS TO BE DRESSED FLUSH.
- BLANK DRAWING -
K FACTOR = 0.5, INSIDE BEND RADIUS = 1 X GAUGE



ISSUE HISTORY ONLY - SEE TITLE BOX FOR LATEST ISSUE

ISSUE:	DATE:	CHANGE:
-	00.00.0000	-



ISOMETRIC VIEW

ISSUE:	DATE:	DESCRIPTION:
A	01/06/2008	Prototype Only

CHANGE:
-



Client DWG No.	SK3584
RA DWG No.	RA 1059-004 PT

SHEET No.
1 of 1

A3

PROJECT No.	RA 1059
-------------	---------

RA A3 L Link