




- DO NOT ALTER THIS DRAWING.
- THIS IS A REFERENCE DRAWING ONLY.
- SEE SolidWorks FILE FOR DETAILS
- IF IN DOUBT ASK.


- REMOVE ALL BURRS AND SHARP EDGES.
- CLEAN AND FULLY DEGREASE.
- ALL WELDS TO BE DRESSED FLUSH.
- BLANK DRAWING -
K FACTOR = 0.5, INSIDE BEND RADIUS = 1 X GAUGE



ISSUE:	DATE:	CHANGE:
-	00.00.0000	-



ISSUE:	DATE:	DESCRIPTION:
A	01/06/2008	Prototype Only



Client DWG No. SK3587
RA DWG No. RA 1059-021 PT

A3

PROJECT No.	RA 1059
-------------	---------



Client DWG No. SK3587
RA DWG No. RA 1059-021 PT

A3



RA A3 L Link