




- DO NOT ALTER THIS DRAWING.
- THIS IS A REFERENCE DRAWING ONLY.
- SEE SolidWorks FILE FOR DETAILS
- IF IN DOUBT ASK.

- REMOVE ALL BURRS AND SHARP EDGES.
- CLEAN AND FULLY DEGREASE.
- ALL WELDS TO BE DRESSED FLUSH.
- BLANK DRAWING -
K FACTOR = 0.5, INSIDE BEND RADIUS = 1 X GAUGE



THIS IS A CAD DRAWING & MUST
NOT BE ALTERED MANUALLY

3RD ANGLE PROJECTION

ISSUE:	DATE:	CHANGE:
-	00.00.0000	-

ISSUE:	DATE:	DESCRIPTION:
A	01/06/2008	Prototype Only
CHANGE: -		



Client DWG No.	SK2494
RA DWG No.	RA 1050-032 PT

SHEET No.
1 of 1

A3

RA 1059