





- DO NOT ALTER THIS DRAWING.
- THIS IS A REFERENCE DRAWING ONLY.
- SEE SolidWorks FILE FOR DETAILS
- IF IN DOUBT ASK.

- REMOVE ALL BURRS AND SHARP EDGES.
- CLEAN AND FULLY DEGREASE.
- ALL WELDS TO BE DRESSED FLUSH.
- BLANK DRAWING -
K FACTOR = 0.5, INSIDE BEND RADIUS = 1 X GAUGE



ISSUE:	DATE:	CHANGE:
-	00.00.0000	-



A3

