






- DO NOT ALTER THIS DRAWING.
- THIS IS A REFERENCE DRAWING ONLY.
- SEE SolidWorks FILE FOR DETAILS
- IF IN DOUBT ASK.

- REMOVE ALL BURRS AND SHARP EDGES.
- CLEAN AND FULLY DEGREASE.
- ALL WELDS TO BE DRESSED FLUSH.
- BLANK DRAWING -
K FACTOR = 0.5, INSIDE BEND RADIUS = 1 X GAUGE



THIS IS A CAD DRAWING & MUST
NOT BE ALTERED MANUALLY

3RD ANGLE PROJECTION

ISSUE:	DATE:	CHANGE:
-	00.00.0000	-

ITEM NO.	PART NUMBER	Std_Part_Ref.	QTY.
1	RA1059-004_PT - Fix Bracket Body	ZUF01109	1
2	RA1059-003_PT - Fix Bracket Arm	ZUF0120	2

ISSUE:	DATE:	DESCRIPTION:
A	01/06/2008	Prototype Only

CHANGE:

-

TITLE: Fixing Bracket Assembly for Powertrack		
PART REFERENCE. ZUF0130		
Client DWG No. SW3656	SHEET No.	A3
RA DWG No. RA 1059-009 SA	1 of 1	

FINISH:

Tolerances:

- Whole numbers ± 0.4
- 1 decimal place ± 0.2
- 2 decimal places ± 0.05

THIS DRAWING MUST NOT BE USED FOR MANUFACTURE UNLESS SPECIFICALLY STATED.

DIMENSIONS IN mm

NDR

1

DATE:
01/06/2008

PROJECT No.	RA 1059
-------------	---------