




- DO NOT ALTER THIS DRAWING.
- THIS IS A REFERENCE DRAWING ONLY.
- SEE SolidWorks FILE FOR DETAILS
- IF IN DOUBT ASK.
- THIS PART TO MATE WITH RA 1059-002-B

- REMOVE ALL BURRS AND SHARP EDGES.
- CLEAN AND FULLY DEGREASE.
- ALL WELDS TO BE DRESSED FLUSH.
- BLANK DRAWING -
K FACTOR = 0.5, INSIDE BEND RADIUS = 1 X GAUGE



ISSUE:	DATE:	CHANGE:
-	00.00.0000	-



ISSUE:	DATE:	DESCRIPTION:
A	01/06/2008	Pre-Production
CHANGE:		
-		



Client DWG No. SK3579-4	SHEET No. 1 of 1	A2
RA DWG No. RA 1059-002-B_PT		

	DRAWN:
	NDR

Tolerances:

Whole numbers ± 0.4
1 decimal place ± 0.2
2 decimal places ± 0.05

Angles $\pm 1^\circ$
Unless Stated

CHECKED

SCALE: 1:1@A2

DATE:
01/06/2008

DIMENSIONS IN mm

PROJECT No.	RA 1059
-------------	---------

