




- DO NOT ALTER THIS DRAWING.
- THIS IS A REFERENCE DRAWING ONLY.
- SEE SolidWorks FILE FOR DETAILS
- IF IN DOUBT ASK.


- REMOVE ALL BURRS AND SHARP EDGES.
- CLEAN AND FULLY DEGREASE.
- ALL WELDS TO BE DRESSED FLUSH.
- BLANK DRAWING -
K FACTOR = 0.5, INSIDE BEND RADIUS = 1 X GAUGE



ISSUE:	DATE:	CHANGE:
-	00.00.0000	-



ISSUE:	DATE:	DESCRIPTION:
A	01/06/2008	Pre-Production



Client DWG No. SK3595
RA DWG No. RA 1059-008 PT

A3

PLASTECH Ltd.
Unit 4, Ricebridge Works, Brighton Road
Bolney, West Sussex, England - RH17 5NA
TEL: 01444 881960 FAX: 01444 881244
E-MAIL: mark@plastch.com
WEB: www.plastch.com

THIS DRAWING IS CONFIDENTIAL AND MUST NOT BE COPIED OR DISCLOSED WITHOUT PRIOR WRITTEN CONSENT.

DIMENSIONS IN mm

PROJECT No.	RA 1059
-------------	---------