




- DO NOT ALTER THIS DRAWING.
- THIS IS A REFERENCE DRAWING ONLY.
- SEE SolidWorks FILE FOR DETAILS
- IF IN DOUBT ASK.

- REMOVE ALL BURRS AND SHARP EDGES.
- CLEAN AND FULLY DEGREASE.
- ALL WELDS TO BE DRESSED FLUSH.
- BLANK DRAWING -  
K FACTOR = 0.5. INSIDE BEND RADIUS = 1 X GAUGE



ISSUE:	DATE:	CHANGE:
-	00.00.0000	-



ISSUE:	DATE:	DESCRIPTION:
A	01/06/2008	Pre-Production



Client DWG No. SK3594	SHEET No. 1 of 1	A3
RA DWG No. RA 1059-007 PT		

**PLASTECH Ltd.**  
Unit 4, Ricebridge Works, Brighton Road  
Bolney, West Sussex, England - RH17 5NA  
TEL: 01444 881960 FAX: 01444 881244  
E-MAIL: [mark@plastch.com](mailto:mark@plastch.com)  
WEB: [www.plastch.com](http://www.plastch.com)

Angles  $\pm 1^\circ$   
Unless Stated

THIS DRAWING IS CONFIDENTIAL AND MUST NOT BE COPIED OR DISCLOSED WITHOUT PRIOR WRITTEN CONSENT.

PROJECT No.	RA 1059
-------------	---------



Client DWG No. SK3594	SHEET No. 1 of 1	A3
RA DWG No. RA 1059-007 PT		

11/09/2008